

# QUICK START GUIDE




REV | #1.15




Manual for Download and Support  
[WWW.LBALTIMETERS.COM](http://WWW.LBALTIMETERS.COM)


## ARES II - QUICK START & ROAD MAP



### Performing ACCESS to Logbook and Jump Info



### Performing ACCESS to Settings



ARES II - QUICK START & ROAD MAP

